

LD419F Non-Penetrating Baseplate



Place the feet of the ladder body into the baseplate and align the pre-drilled holes with the middle, front groove of the ladder stile.



Fasten with (2) #12 x 3/4in S/S tek screws through the pre-dilled holes on each side of the ladder.